




paparazzi™

Rotating Tabletop Accessory Display Assembly Instructions



Step 1: Remove all pieces from the box. There should be a total of seven.



Step 4: Thread the rod through the hole in one of the square end pieces. Attach one washer followed by the acorn nut to the side of the square end piece without grooved slots along its edge. Tighten to secure. This will be the top of your finished display.



Step 2: Remove all packaging material to reveal individual pieces:

- 4 Pegboards
- 4 Mirror Strips
- 2 Square End Pieces with Grooved Edges
- 1 All-Thread Rod
- 1 Base
- 1 Spinner Base
-



Step 5: Flip the square end piece facedown: the acorn nut should be facing down and the slots of the square end piece facing up.

Slide each of the pegboards into the grooved edges of the square end piece and attach the mirror strips on each corner. Press the pieces into place from the side and do not slide them vertically.

Note: Make sure the same ends of each pegboard are facing the same direction to ensure an even display.



Step 3: Remove washers, nuts, and acorn nut from the all-thread rod.



Step 6: Thread the exposed end of the all-thread rod through the hole in the other square end piece and slide the pegboards into its grooved edges.



paparazzi™

Rotating Tabletop Accessory Display Assembly Instructions



Step 7: Screw a nut onto the end of the all-thread rod to secure the square end piece.



Step 11: Screw the remaining two nuts on top of the washer to secure.



Step 8: Place the flat side of the ball-bearing spinner base into the ridge on the circular base.



Step 9: Slide base onto the all-thread rod.



Step 10: Place washer onto the end of the all-thread rod.



Your completed display should look like this.